

## **5.14 PARKING**

1. Parking Brake - ON

2. Idle Levers - FEATHER

3. Condition Levers - FUEL CUT OFF

4. Avionics OFF OFF 5. Fuel Pump Switches 6. Yellow System OFF 7. Fuel Valves Closed 8. PP2 DC Switches OFF 9. Generators 1, 2, 3, 4 & 5 OFF 10. All artificial fuel switches OFF 11. Auto pilot master switches OFF 12. Battery 1 & 2 OFF 13. Vibration Switches OFF

14. Trim - NEUTRAL